

Cross-beam Area Sensor

■ Features

- 3-point cross-beam netting method minimizes non-sensing area and increases sensing ability
- Long sensing distance 7m
- 7 models of number of optical axes (4 to 20EA) and optical axis pitch(40,80mm), sensing height(120 to 1,040mm)
- Easy installation by installation mode function
- Built-in interference protection, self-diagnosis function
- High luminance indicators for emitter and receiver to check the status at side, front, and long distance
- Protection structure IP65(IEC structure)

⚠ Please read "Caution for your safety" in operation manual before using.



NEW



■ Applications

Screen door for subway platform and dangerous industry environment

■ Ordering information

BWC **40** - **14** **H**

Item	Operation mode	H	Light ON
		HD	Dark ON
	Number of optical axes	Number	4 to 20EA
	Optical axis pitch	40	40mm pitch
		80	80mm pitch
	BWC	Cross-beam area sensor	


■ Specifications

Model	BWC40-□□H	BWC40-□□HD	BWC80-14H	BWC80-14HD	
Sensing type	Through-beam type				
Sensing distance	1.0 to 7.0m				
Sensing target	Opaque material of min. Ø50mm		Opaque material of min. Ø90mm		
Optical axis pitch	40mm		80mm		
Number of optical axes	4/10/12/16/18/20EA		14EA		
Sensing height	120 to 760mm		1,040mm		
Beam pattern	3-point cross-beam netting type				
Power supply	12-24VDC ±10%(ripple P-P : max. 10%)				
Reverse polarity protection	Built-in				
Current consumption	Max. 100mA				
Control output	NPN open collector output •Load voltage: max. 30VDC, •Load current: Max. 100mA, •Residual voltage: Max. 1V				
	Operation mode	Light ON	Dark ON	Light ON	Dark ON
	Short-circuit protection	Built-in			
	Response	Max. 50ms			
Light source	Infrared LED(850nm modulated light type)				
Synchronization type	Timing method by synchronous cable				
Self-diagnosis	Transmitted-received light monitoring, direct light monitoring, output circuit monitoring				
Interference protection	Interference protection by frequency changing setting				
Environment	Ambient illumination	Ambient light: Max. 100,000lx (received light side illumination)			
	Ambient temperature	-10 to 55°C, storage: -20 to 60°C			
	Ambient humidity	35 to 85%RH, storage: 35 to 85%RH			
Protection	IP65(IEC standard)				
Noise resistance	±240V the square wave noise (pulse width: 1μs) by the noise simulation				
Dielectric strength	1,000VAC 50/60Hz for 1 min.				
Insulation resistance	Min. 20MΩ (at 500VDC megger)				
Vibration	1.5mm amplitude or 300m/s ² at frequency of 10 to 55Hz(for 1 min.) in each of X, Y, Z directions for 2 hour				
Shock	500m/s ² (approx. 50G) in each of X, Y, Z directions for 3 times				
Material	Case: Aluminum, Sensing part and indicator: Acrylic				
Cable	Ø5, 4-core, length: 300mm, M12 connector				
Accessory	Bracket A : 4EA, Bracket B : 4EA, Fixing bolt: 8EA				
Approval	CE				
Unit weight	Approx. 1.7kg (based on BWC80-14H)				

※The temperature or humidity mentioned in Environment indicates a non freezing or condensation environment.


Cross-beam Area Sensor

Feature data




Dimensions

(unit : mm)




BWC40 Series
Optical axis
pitch:40




Model	L(mm)
BWC40-04H/HD	180mm
BWC40-10H/HD	420mm
BWC40-12H/HD	500mm
BWC40-16H/HD	660mm
BWC40-18H/HD	740mm
BWC40-20H/HD	820mm
BWC80-14H/HD	1140mm


• Bracket A



• Bracket B




• Mounting brackets



- (A) Photo electric sensor
- (B) Fiber optic sensor
- (C) Door/Area sensor
- (D) Proximity sensor
- (E) Pressure sensor
- (F) Rotary encoder
- (G) Connector/Socket
- (H) Temp. controller
- (I) SSR/ Power controller
- (J) Counter
- (K) Timer
- (L) Panel meter
- (M) Tacho/ Speed/ Pulse meter
- (N) Display unit
- (O) Sensor controller
- (P) Switching mode power supply
- (Q) Stepper motor& Driver&Controller
- (R) Graphic/ Logic panel
- (S) Field network device
- (T) Software
- (U) Other

BWC Series


■ Connection cable(sold separately)



Type	Model	L	Cable color
For emitter	CID4-3T	3m	Black
	CID4-5T	5m	
	CID4-7T	7m	
	CID4-10T	10m	
For receiver	CID4-3R	3m	Gray
	CID4-5R	5m	
	CID4-7R	7m	
	CID4-10R	10m	

※Connection cable is sold separately as one set; each of emitter's and receiver's.


■ Optical axis pitch/Number of optical axes/Sensing height



Model	Optical axis pitch
BWC40-□H/HD	40mm
BWC80-□H/HD	80mm

Model	No. of optical axes	Sensing height
BWC40-04H/HD	4EA	120mm
BWC40-10H/HD	10EA	360mm
BWC40-12H/HD	12EA	440mm
BWC40-16H/HD	16EA	600mm
BWC40-18H/HD	18EA	680mm
BWC40-20H/HD	20EA	760mm
BWC80-14H/HD	14EA	1,040mm

■ Structure




< Operation indicator >

LED color	Emitter	Receiver
Green	Power	Stable light ON
Yellow	—	Unstable area
Red	Installation mode	Stable light OFF

<Wiring connection>

Pin No	Cable color	Emitter	Receiver
1	Brown	12-24VDC	12-24VDC
2	White	Sync	Sync
3	Blue	0V	0V
4	Black	Mode	OUT

■ Control output circuit




Cross-beam Area Sensor

■ Operation mode

Operation mode	Light ON		Dark ON	
Receiver	Received light		Received light	
	Interrupted light		Interrupted light	
Operation indicator (Green LED)	ON		ON	
	OFF		OFF	
Transistor output	ON		ON	
	OFF		OFF	

■ Operation timing diagram



■ Functions

◎ Interference protection

You can change transmitted light frequency to prevent interference from several units.
To change transmitted light frequency, input 0V to no. 4 terminal (black) MODE (for over 1 sec.) of Emitter during normal operation.
Frequency type is displayed by the frequency indicator.

☼ : ON, ● : OFF

Transmitted light frequency	Frequency indicator		
	Green 1	Green 2	Green 3
Frequency A	☼	●	●
Frequency B	●	☼	●
Frequency C	●	●	☼
Frequency D	☼	●	☼
Frequency E	☼	☼	☼

◎ Installation mode

This function is for stable installation.
To enter installation mode, supply the power with inputting 0V to no. 4 terminal (black) MODE of Emitter.

☼ : ON, ● : OFF, ◐ : Flash

Item	Emitter		Receiver			Control output
	Green	Red	Green	Yellow	Red	
Normal installation	●	◐	☼	●	◐	OFF
Hysteresis section	●	◐	●	☼	◐	OFF
Abnormal installation	●	◐	●	●	◐	OFF

◎ Self-diagnosis

If there is malfunction during normal operation by regular self-diagnosis, control output turns OFF and operation indicator displays the state.

●Diagnosis items

- | | |
|---|------------------------------------|
| ① Break of light emitting element | ④ Break of receiver |
| ② Break of Emitter | ⑤ Emitter failure |
| ③ Break of adjacent emitting elements more than 2EA | ⑥ Malfunction of synchronous cable |

※ For more information about operation indication display, refer to "■ Operation indicator DISPLAY" at C-20 page.

(A) Photo electric sensor
(B) Fiber optic sensor
(C) Door/Area sensor
(D) Proximity sensor
(E) Pressure sensor
(F) Rotary encoder
(G) Connector/Socket
(H) Temp. controller
(I) SSR/ Power controller
(J) Counter
(K) Timer
(L) Panel meter
(M) Tacho/ Speed/ Pulse meter
(N) Display unit
(O) Sensor controller
(P) Switching mode power supply
(Q) Stepper motor& Driver&Controller
(R) Graphic/ Logic panel
(S) Field network device
(T) Software
(U) Other

BWC Series


■ Installation

For the first installation, enter installation mode.

- ① Entry method for installation mode: Supply the power with inputting 0V to no. 4 terminal (black) MODE of Emitter.
- ② After entering installation mode, install the unit at the position where green LED of receiver operation indicator turns ON.
- ③ After installation, re-supply the power to the unit.


◎ For direction of installation

Emitter-Receiver should be installed in same up/down direction.



◎ For reflection from the surface of wall/flat


When installing it as below, the light reflected from the surface of wall and flat is not shaded. Please check whether it operates normally or not with a sensing target before using. (interval distance: min. 0.5m)




◎ For protection of interference

It may cause interference when installing more than 2 sets of the sensor. In order to avoid the interference of the sensor, please install as following figures and use interference protection function


< Transmission direction should be opposite between 2 sets >



< Baffle should be installed between 2 sets >



<It should be installed out of the interference distance>



■ Operation indicator DISPLAY

Item	Emitter		Receiver				
	Indicator	Indicator	Indicator	Indicator	Control output	Control output	
	Green	Red	Green	Yellow	Red	Light ON	Dark ON
Power supply	☀	●	—	—	—	—	—
Break of emitter	▶▶	◀◀	—	—	—	—	—
Break of light emitting element	▶	▶	◀	▶	▶	OFF	ON
Break of adjacent emitting elements more than 2EA	◐	◐	▶	▶	▶	OFF	ON
Stable light ON	—	—	☀	●	●	ON	OFF
Unstable light ON	—	—	☀	☀	●	ON	OFF
Unstable light OFF	—	—	●	☀	☀	OFF	ON
Stable light OFF	—	—	●	●	●	OFF	ON
Break of receiver	—	—	▶▶	●	◀◀	OFF	ON
Control output over current	—	—	▶	◀	☀	OFF	ON
Synchronous line malfunction	—	—	◐	●	◐	OFF	ON
Emitter failure (time out)	—	—	◐	◐	◐	OFF	ON

Indicators	
☀	Lighting
●	Light out
◐	Flashing by 0.5 sec.
◐ ◐ or ◐ ◐	Flashing simultaneously by 0.5 sec.
▶▶	Cross-flashing by 0.5 sec.
▶▶▶	Cross-flashing by 0.5 sec.

■ Troubleshooting

Malfunction	Causes	Troubleshooting
Non-operation	Power supply	Supply the rated power.
	Cable incorrect connection or disconnection	Check the wiring connection.
Non-operation in sometimes	Out of rated sensing distance	Use it within rated sensing distance.
	Pollution by dirt of sensor cover	Remove dirt by soft brush or cloth.
Control output is OFF even though there is not a target object.	Connector connection failure	Check the assembled part of the connector.
	Out of the rated sensing distance	Use it within the rated sensing distance.
	There is an obstacle to cut off the emitted light between emitter and receiver	Remove the obstacle.
Operation indicator displays break of emitter	There is strong electric wave or noise generator such as motor, electric generator, or high voltage line, etc.	Separate the strong electric wave or noise generator.
	Break of emitter	Contact our service center.
Operation indicator displays break of receiver	Break of receiver	
Operation indicator displays break of light emitting elements	Break of light emitting element	
Operation indicator displays emitter failure	Emitter failure	Check the wiring connection in emitter and receiver.
	Bad wiring connection of synchronous cable in emitter and receiver	
Check the wiring connection in emitter and receiver	Control output line is shorted out.	Check the wiring connection.
	Over load	Check the rated load capacity.